


Mosquito Walkalong Glider Pattern

Add a little tape to the front weight for more weight; cut off a little for less weight.



5 cm between lines
SCALE CHECK
2 inches between lines

When printing it is possible for the size of the patterns to become distorted-usually smaller. In the print dialogue box of Acrobat Reader and Safari, do not allow "fit to page"; instead look for "100%" or something similar. For Explorer and Mozilla go to File, Page Setup, and uncheck the "shrink to fit" or similar option. After you print out, there is a 2 inch/5 centimeter scale check to make sure it's correct.

CAUTION: The thin foam used for the Mosquito glider could be a choking hazard for small children.